

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

**READ ALL INSTRUCTIONS BEFORE USING. KEEP AWAY FROM WATER.**

### DANGER

Any appliance is electrically live even when the switch is off. To reduce the risk of death or injury by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

## USER MAINTENANCE

Your dryer is virtually maintenance free. No lubrication is needed. The dryer must be kept clean for proper operating performance. When cleaning is needed, unplug the cord, allow to cool and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a damp cloth only.

**Blocked or clogged air intake vents will cause the dryer to overheat.** If overheating occurs, an automatic safety device will shut the dryer or the heat off to prevent damage or personal injury. If the unit or the heat cycles off, turn the dryer off, unplug the cord, and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

### CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short circuit. Inspect the cord frequently for damage. **Stop use immediately if damage is visible or unit stops or operates intermittently.**

If the cord or dryer is damaged or does not operate properly, return it for repair to place of purchase or an authorized BaBylissPRO service representative only. No repairs should be attempted by the consumer.

## WARNING

To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. This appliance should not be used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. **Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped, damaged, or dropped into water. Return the appliance to place of purchase for examination and repair.**
5. Keep the cord away from heated surfaces. **Do not pull, twist, or wrap line cord around dryer.**
6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and other debris.
7. Never use while sleeping.
8. Never drop or insert objects into any opening.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord to operate dryer.

### STORAGE – IMPORTANT

When not in use, your dryer should be disconnected, allowed to cool and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer. Allow the cord to hang or lie loose and straight at the point of entry into the dryer.


### LIMITED 2-YEAR WARRANTY (U.S. only)

BaBylissPRO will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on back, together with your purchase receipt and \$15.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-326-6247 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

11. Do not direct hot air toward eyes or other heat-sensitive areas.
12. **Air outlet grille and attachments may be very hot during use. Allow them to cool before handling.**
13. Do not place appliance on any surface while operating.
14. While using the appliance, keep your hair out of it. Keep your hair away from the air inlets.
15. To prolong the life of the dryer, keep filters clear of hair and dust.
16. Do not use with a voltage converter.
17. This appliance is not a toy. Keep away from children.

18. **Warning:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water. 
19. When the hair dryer is used in bathroom, unplug it after use since the proximity of water presents a hazard even when the hair dryer is switched off.
20. For additional protection, the installation of, the installation of a residual current device (RCD), having a rated residual operating current not exceeding 30mA, is advisable in the electrical circuit supplying the bathroom. Ask your electrician for advice.
21. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance

**IN NO EVENT SHALL BABYLISSPRO BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

### SERVICE CENTER

BaBylissPRO  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

©2021 Professional Products Division

19BA063596

IB-16500A

by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.

## SAVE THESE INSTRUCTIONS

## OPERATING INSTRUCTIONS

This appliance is intended for professional or household use. Use on Alternating Current (60 hertz) only. Standard dryers are designed to operate at 125 volts AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

## IMPORTANT 1875 WATT OPERATING GUIDE


Use of this dryer on the same circuit or fuse with other electrical products or appliances may trip a 15 amp circuit breaker or blow a 15 amp fuse. **NEVER replace the fuse with one rated higher than the capacity of the circuit. Doing so could result in an electrical fire.**

### CHECK ALCI SAFETY FEATURE EVERY TIME YOU USE DRYER.

This hair dryer is equipped with an Appliance Leakage Circuit Interrupter (ALCI), a safety feature that renders it inoperable under some abnormal conditions, such as immersion in water.

To make sure the ALCI is functioning properly, perform the following test; the purpose of this test is to allow you to make sure the exclusive water sensing system (ALCI) is working:

1. Plug in hair dryer and press test button on plug (see appropriate diagram).
2. Hair dryer will stop working. There will be an audible click and reset button will pop out. This indicates the ALCI is functioning properly.
3. To reset ALCI with a reset button, unit should be unplugged. Then push reset button in, and reinsert plug into outlet.



4. If ALCI is not functioning properly, return hair dryer to place of purchase.

5. It is important that if immersion occurs, this unit be brought to a service center. Do not try to reset.
6. Be sure to repeat test every time you use hair dryer to confirm ALCI is operational.
7. Should the dryer go off and the ALCI reset button pop up during use, this could indicate a malfunction in the dryer. Remove plug from outlet and allow the dryer to cool. Push the reset button in and reinsert plug into outlet. Dryer should function normally. If not, return it to a BaBylissPRO Service Center for examination and repair.

### SUPER STYLING GUIDE

Your best looks begin with a good haircut that's well maintained. Always treat hair well with superior quality shampoos, conditioners, and finishing products.

### DRYING BASICS

1. Shampoo and condition hair with products of your choice. Rinse thoroughly. Towel-blot hair to remove excess moisture. Section hair. Using the dryer along with your styling brush, direct hot air through one section of hair at a time. Move dryer steadily across each section so that the hot air passes through hair. Direct airflow at hair, not scalp.
2. Keep dryer's air intake vents unobstructed and free from hair while drying.
3. To avoid overdrying and possible damage to

hair or skin, do not concentrate heat on one section for any length of time. Keep dryer moving as you style.

4. For quick touch-ups between shampoos, dampen hair with a mist of water before styling with the dryer.
5. When using your dryer to create curls and waves, dry hair almost completely on a warmer temperature setting, then finish styling with cooler air.
6. This dryer includes a concentrator attachment. Use the attachment when you need drying power in a small area (such as a curl or a wave), or when you want to relax curly hair.

**THE IONIZING FUNCTION** generates a cloud of negative ions that can:

- help reduce frizz by up to 75%\*
- neutralize the generally positive charge on flyaway, frizzy hair
- eliminate static electricity
- contribute to shine

*\*When compared to hair dryers with natural ion generation*

**WARNING**  
**THIS APPLIANCE IS DESIGNED EXCLUSIVELY FOR USE BY LICENSED COSMETOLOGISTS.**

électrique alimentant la salle de bain. Demander conseil à un électricien.

21. Cet appareil ne devrait pas être utilisé par des enfants ou des personnes souffrant d'un handicap physique, mental ou sensoriel, ou qui ne disposent pas des connaissances ou de l'expérience nécessaires, à moins qu'une personne responsable de leur sécurité leur en ait expliqué le fonctionnement ou les encadre lors de son utilisation. Il convient de surveiller les enfants afin de s'assurer qu'ils ne jouent pas avec l'appareil.

## GARDER CES INSTRUCTIONS

## DIRECTIVES D'UTILISATION

Cet appareil est destiné à un usage professionnel ou domestique. Brancher l'appareil sur courant alternatif (60 Hz) uniquement. Cet appareil a été conçu pour fonctionner avec un courant de 125 V.

Cet appareil est doté d'une fiche polarisée (une broche est plus large que l'autre). Par mesure de sécurité, cette fiche s'insèrera dans la prise de courant d'une seule façon. Si la fiche ne s'insère pas bien, la renverser. Si elle ne s'insère toujours pas, contacter un électricien qualifié. Ne jamais essayer de contrer cette mesure de sécurité.

### GET TO KNOW YOUR HAIR DRYER

#### Models BY5175UC/BB5175UC



### STYLING TIPS

#### BODY & VOLUME

To create extra volume, bend head upside down while drying. Position the airflow toward the roots for maximum lift. When hair is dry, toss head back and brush hair into place.



#### STRAIGHTENING

Work with hair in sections when creating a super straight look. Using a large round brush (approximately 2" in diameter), hold hair taut in each section and bend ends slightly under as you dry.



#### MAKING WAVES

Tousled, natural-looking waves are easily created by grasping hair at the roots and scrunching between fingertips while drying.



This message about...

**G**ROUND

**F**AULT

**C**IRCUIT

**I**NTERRUPTERS

...can save a life!

### rudiments du séchage

1. Laver et revitaliser les cheveux à l'aide des produits de votre choix. Rincer abondamment. Essorer les cheveux à la serviette. Diviser les cheveux en sections uniformes. Sécher chaque section à l'aide du séchoir et d'une brosse. Déplacer le séchoir lentement et régulièrement des racines jusqu'aux pointes, en dirigeant l'air chaud vers les cheveux, pas le cuir chevelu.
2. Veiller à ce que les orifices de ventilation ne soient pas obstrués par des cheveux durant le séchage.
3. Pour éviter d'abîmer les cheveux, ne pas diriger la chaleur sur un point fixe pendant une période prolongée ; déplacer le séchoir constamment.
4. Pour effectuer des retouches rapides entre les shampooings, humecter les cheveux à l'aide d'un vaporisateur puis passer au brushing.
5. Lorsque vous utilisez le séchoir pour boucler ou ondule les cheveux, sécher les cheveux presque complètement en utilisant un réglage de température chaud, puis terminer le séchage en utilisant de l'air froid.
6. Ce séchoir inclut un concentrateur d'air. Utilisez le concentrateur lorsque vous avez besoin d'une certaine puissance de séchage sur une petite zone, comme une boucle ou une ondulation, ou pour lisser les cheveux.

**LA FONCTION IONIQUE** génère un nuage d'ions négatifs qui peuvent :  
• aider à réduire les frisottis jusqu'à 75 %\*

**IF YOU MUST USE YOUR HAIR DRYER IN THE BATHROOM, INSTALL A GFCI\* NOW!**

Your local electrician can help you decide which type is best for you – a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCIs in the bathrooms, garages, and outdoor outlets of all new homes.

#### WHY DO YOU NEED A GFCI?



Electricity and water don't mix. If your hair dryer falls into water while it's plugged in, the electric shock can kill you...even if the switch is off. A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.

**A GFCI can save your life! Compared to that, the price is small! Don't wait...install one now!**

\*A GFCI is a sensitive device that reacts immediately to a small electric current leak by stopping the flow of electricity.

- neutraliser la charge positive des cheveux frisottés
  - éliminer l'électricité statique
  - donner de la brillance
- \*En comparaison avec les séchoirs avec source naturelle d'ions*

**AVERTISSEMENT**  
**CET APPAREIL A ÉTÉ CONÇU EXCLUSIVEMENT POUR LES COIFFEURS PROFESSIONNELS.**

**FAMILIARISEZ-VOUS AVEC VOTRE SÉCHOIR**

#### Modèles BY5175UC/BB5175UC



