

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

## DANGER

Any appliance is electrically live even when the switch is off. To reduce the risk of death or injury by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or other liquids.
5. If an appliance falls into water, unplug it

## CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the hot air styler. Damage will occur at the high flex point of entry into the hot air styler, causing it to rupture and short circuit. Inspect the cord frequently for damage. **Stop use immediately if damage is visible or unit stops or operates intermittently.**


If the cord or hot air styler is damaged or does not operate properly, return it for repair to an authorized BaBylissPRO service representative only. No repairs should be attempted by the consumer.

## STORAGE – IMPORTANT

When not in use, your hot air brush should be disconnected, allowed to cool and stored in a safe, dry location, out of reach of children. Do not wrap line cord around hot air styler. Allow the cord to hang or lie loose and straight at the point of entry into the hot air styler.

## WARNING

To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. This appliance should not be used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped, damaged, or dropped into water. Return the appliance to place of purchase for examination and repair.
5. Keep the cord away from heated surfaces. Do not pull, twist, or wrap line cord around appliance.
6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and other debris.
7. Never use while sleeping.
8. Never drop or insert objects into any opening.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord to operate appliance.
11. Do not direct hot air toward eyes or other heat-sensitive areas.
12. Air outlet grille and attachments may be very hot during use. Allow them to cool before handling.
13. Do not place appliance on any surface while operating.
14. While using the appliance, keep your hair out of it. Keep your hair away from the air inlets.
15. To prolong the life of the appliance, keep filters clear of hair and dust.
16. Do not use with a voltage converter.
17. This appliance is not a toy. Keep away from children.
18. **Warning:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water. 
19. When the hair dryer is used in bathroom, unplug it after use since the proximity of water presents a hazard even when the hair dryer is switched off.
20. For additional protection, the installation of a residual current device (RCD),

## HASSLE-FREE 2-YEAR WARRANTY

This warranty is available only to consumers who purchase products directly from BaBylissPRO or an authorized BaBylissPRO reseller. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners or consumers who purchase from unauthorized BaBylissPRO resellers.

BaBylissPRO will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials and was purchased directly from BaBylissPRO or an Authorized BaBylissPRO Reseller.

Your ultimate satisfaction in BaBylissPRO products is our goal so if your item should fail within the generous warranty period, we will repair it and/or if necessary, replace it at no cost to you. To obtain a return shipping label email us at <https://babilisspro.com/warranty-page>. Or call our toll free customer service department at 800-326-6247 to speak with a representative.

In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture. **ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT**

having a rated residual operating current not exceeding 30mA, is advisable in the electrical circuit supplying the bathroom. Ask your electrician for advice.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.

## SAVE THESE INSTRUCTIONS

## OPERATING INSTRUCTIONS

This appliance is intended for professional or household use. Use on alternating current (60 hertz) only. Standard appliances are designed to operate at 125 volts AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.


## IMPORTANT 1000 WATT OPERATING GUIDE

Use of this appliance on the same circuit or fuse with other electrical products or appliances may trip a 15 amp circuit breaker or blow a 15 amp fuse. **NEVER replace the fuse with one rated higher than the capacity of the circuit. Doing so could result in an electrical fire.**

## IMPORTANT SAFETY PLUG INSTRUCTIONS

This hair dryer is equipped with an auto monitoring ALCI safety plug.

READ AND SAVE THE INSTRUCTIONS PROVIDED IN A SEPARATE LEAFLET.



**TRUE IONIC TECHNOLOGY** Many aspects of modern living, including air conditioning, contact with man-made fibers, and air pollution contribute to a buildup of static electricity in the hair. Even brushing and towel-drying the hair can increase these levels, causing the surface of the cuticle to become rough. Consequently, hair may have a dull appearance. Also, high levels of static charge cause hair to become flyaway and difficult to style. The ion generator produces a stream of negative ions that act to neutralize the static charge, smoothing the cuticle for shiny, smooth and manageable hair, so you can achieve your desired style easily.

**NANO TITANIUM™ TECHNOLOGY** Nano titanium™ is an exceptional conductor of heat and is stable in ultra-high temperatures. This technology uses microparticles of titanium that provide the ultimate heat performance for beautiful, healthy-looking hair.

### 3 SETTINGS

**Low Setting:** This position combines ideal airflow and temperature setting for shaping finer, damaged or treated hair.

**High Setting:** Combines ideal airflow with higher temperature, especially recommended for pre-drying and also for styling thick hair.

**Cool Setting:** Using the cool setting at the end sets the style for a long-lasting effect.

## INSTRUCTIONS FOR USE

Use a hairdryer first to dry hair and remove the excess moisture. Once the hair is 80% dry, you can start to create your style using the BaBylissPRO® Oval Ionic Hot Air Brush.

### SUPER STYLING GUIDE

Always treat hair right with superior quality shampoos, conditioners, and finishing products. The BaBylissPRO® Oval Ionic Hot Air Brush is an innovative, revolutionary hot air styler that has effectively eliminated the need for a hair brush or a dryer. The BaBylissPRO® Oval Ionic Hot Air Brush is perfect for adding gorgeous volume and shine to styles. The large barrel gives fullness and body as you style while the combination bristles create ultimate shine and smoothness.

### FEATURES

- 1000 watts
- High shine—true ionic conditioning
- 2.5" barrel with tangle-free combination bristles
- 2 heat settings plus cool setting
- High-performance DC motor
- Easy-to-clean removable filter
- Professional power cord

## Styling Tips for Maximum Volume and Body

1. Start by sectioning the hair. Be sure to comb through hair so it's detangled.
  2. To turn the appliance on, select the correct heat setting based on hair type.
  3. Position the appliance in the hair close to the roots, and brush through the section.
  4. Move the brush through the hair toward the ends, and as you reach the end of the section, start to rotate the brush away from the head.
  5. As you do this, pull the brush downward. Tension created through the section of hair will help to smooth hair faster.
- IMPORTANT!** It may take several attempts to perfect this technique.
6. For added root lift, hold the brush in place at the roots for a few seconds.
  7. For even more volume, rotate the brush, winding the entire section of hair around the barrel. Then leave the brush in the hair for a few seconds. Use cool style setting to set style.
  8. To release the section, unwind the hair from the brush.

## INSTRUCCIONES DE OPERACIÓN IMPORTANTES DE SEGURIDAD ACERCA DEL ENCHUFE

Este aparato cuenta con un enchufe equipado con un interruptor de control de potencia (ALCI, por sus siglas en inglés) automático.

LEA Y GUARDE LAS INSTRUCCIONES PROPORCIONADAS EN EL FOLLETO ADJUNTO.

## FAMILIARÍCESE CON SU CEPILLO CALIENTE



9. Repeat as necessary.
10. After use, switch off and unplug the appliance.
11. Allow to cool before storing away.

### Helpful Hints and Tips

- To define layers and give shape to styles, follow step 4 and repeat through all sections.
- To get root volume and body through the top section of hair, follow steps 3 to 6, but using an upward motion.
- You can create flips or tuck hair under. Also perfect for shaping bangs.

## CLEANING AND MAINTENANCE

- Unplug the appliance and let cool completely before cleaning it.
- Use a damp cloth and clean carefully. Make sure the appliance is completely dry before using again.
- The rear filter should be cleaned using a soft brush on a regular basis to help prevent buildup and overheating. This will also prolong the motor life.



This message about...

GROUND

FAULT

CIRCUIT

INTERRUPTERS

...can save a life!



...can save a life!

## IMPORTANT

Never immerse this product in water or any other liquids.

IF YOU MUST USE YOUR HOT AIR STYLER IN THE BATHROOM, INSTALL A GFCI\* NOW!

Your local electrician can help you decide which type is best for you – a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCIs in the bathrooms, garages, and outdoor outlets of all new homes.

### WHY DO YOU NEED A GFCI?

Electricity and water don't mix. If your hot air styler falls in water while it's plugged in, the electric shock can kill you...even if the switch is

off. A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.

**A GFCI can save your life! Compared to that, the price is small! Don't wait... install one now!**

\*GFCI is a sensitive device that reacts immediately to a small electric current leak by stopping the electricity flow.

## CARACTERÍSTICAS

- 1000 vatios
- Acondicionamiento iónico para mayor brillo
- Cuerpo 2.5 in. (64 mm) con una combinación de cerdas especialmente diseñadas para evitar los enredos
- 2 ajustes de temperatura, más aire frío
- Motor DC de alto rendimiento
- Filtro removible de fácil limpieza
- Cable profesional

## INSTRUCCIONES DE USO

Se recomienda presecar el cabello con un secador para eliminar el exceso de humedad. Cuando el cabello esté seco al 80 %, peineo con el cepillo de aire iónico ovalado BaBylissPRO®.

**GUÍA PARA UN SÚPER PEINADO** Siempre cuide su cabello con champús, acondicionadores y productos de peinado de calidad superior. El cepillo de aire iónico ovalado BaBylissPRO® es una herramienta revolucionaria que combina los beneficios de un cepillo y de un secador de cabello. Es ideal para crear hermosos peinados, con mucho cuerpo y brillo. El cuerpo grande del cepillo proporciona cuerpo y volumen mientras sus cerdas suaves suavizan el cabello y ofrecen un brillo increíble.

### 3 AJUSTES

**"LOW" (bajo):** Ideal para el cabello fino, dañado o tratado.

**"HIGH" (alto):** Perfecto para presecar el cabello y peinar el cabello grueso.

**COOL (tibio):** Fija el peinado para estilos que duran más tiempo.

## USER MAINTENANCE

Your hot air brush is virtually maintenance free. No lubrication is needed. For proper operating performance, the hot air brush must be kept clean. When cleaning is needed, unplug the cord, allow to cool and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the hot air brush should be wiped clean with a cloth only. **Blocked or clogged air intake vents will cause the hot air styler to overheat.** If overheating occurs, an automatic safety device will shut the hot air styler or the heat off to prevent damage or personal injury. If the unit or the heat turns off, unplug the cord and allow the hot air styler to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

**¡IMPORTANT!** Esta técnica requiere práctica.

6. Para dar volumen a la raíz, coloque el cepillo debajo de la sección de cabello, cerca del cuero cabelludo, y manténgalo en esta posición por varios segundos.
7. Para obtener aún más volumen, gire el cepillo para enrollar la sección de cabello alrededor del mismo. Mantenga el cepillo en esta posición por unos segundos. Use el aire frío para fijar el peinado.
8. Para soltar el cabello, desenrótlelo suavemente del cepillo.
9. Repita hasta obtener el resultado deseado.
10. Apague y desenchufe el aparato después del uso.
11. Permita que se enfríe antes de guardarlo.

## Consejos para obtener máximo volumen y cuerpo

1. Divida el cabello en secciones uniformes. Peine el cabello para desenredarlo.
2. Encienda el aparato y ajuste la temperatura al nivel deseado según su tipo de cabello.
3. Coloque el cepillo debajo de una sección de cabello, cerca del cuero cabelludo,
4. Baje el cepillo lentamente hacia las puntas. Al llegar a las puntas, gire el cepillo hacia fuera.
5. Mientras gira el cepillo, deslicelo lentamente hacia abajo para crear tensión; esto ayudará a suavizar el cabello más rápidamente.

